**Fig. 1**

2000





Fig. 2

3000**Fig. 3**

4000




Fig. 4

5000

Configuration Wizard
Use this for the initial configuration of a network interface device

This wizard will help you configure the network interface device in order to connect to a non-process network

To configure the network interface device specify the device's position relative to the programmable logic controller. Click 'read modules' to search for the installed network interface device

Module Position

	⬆ 5450
5400	⬇ 5475

Read Modules

5500

Position	Module ID
5650	5675
	5600

5300

5200

< Back 5700

Next > 5800

Cancel 5900

5100

Fig. 5